

FME-Connectors and adapters for interconnection of FME-cables

DESCRIPTION

Amphenol Procom FME connectors and adapters are RoHs & REACH compliant.



ORDERING DESIGNATIONS

TYPE	PRODUCT NO.	DESCRIPTION	
FME-RG 58	130000559	Basis FME-connector for crimping on RG 58	
FME-RG 174	130000560	Basis FME-connector for crimping on RG 174	
MFME-RG 58	130000562	Male FME-connector for crimping on RG 58	
MFME-RG 174	130000563	Male FME-connector for crimping on RG 174	
FME-P	130000565	Extension (male to male) connector for interconnection of FME-cables	
FME-FME	130000583	FME extension connector, female to female	
FME-BNC	130000566	FME ◆ BNC (male) connector	
FME-TNC	130000569	FME ◆ TNC (male) connector	
FME-N	130000571	FME ◆ N (male) connector	
FME-UHF	130000572	FME ◆ UHF (male) connector	
FME-MUHF	130000573	FME ◆ Mini-UHF (male) connector	
FME-SMA	130000577	FME ◆ SMA (male) connector	
FME-FSMA	130000578	FME ◆ SMA (female) connector	
BFME-ICOM	140000041	Black FME ◆ ICOM connector for interconnection of FME-cables	
FME-EBNC	130000580	FME ◆ elbow-BNC (male) connector	
FME-ETNC	130000581	FME ◆ elbow-TNC (male) connector	
FME-EMUHF	130000582	FME ◆ elbow-MUHF (male) connector	

ORDERING

Type	Product No.	Description
FME-RG 58	130000559	Basis FME-connector for crimping on RG 58
FME-RG 174	130000560	Basis FME-connector for crimping on RG 174
MFME-RG 58	130000562	Male FME-connector for crimping on RG 58
MFME-RG 174	130000563	Male FME-connector for crimping on RG 174
FME-P	130000565	Extension (male to male) connector for interconnection of FME-cables
FME-FME	130000583	FME extension connector, female to female
FME-BNC	130000566	FME → BNC (male) connector
FME-TNC	130000569	FME → TNC (male) connector
FME-N	130000571	FME → N (male) connector
FME-UHF	130000572	FME → UHF (male) connector
FME-MUHF	130000573	FME → Mini-UHF (male) connector
FME-SMA	130000577	FME → SMA (male) connector
FME-FSMA	130000578	FME → SMA (female) connector
BFME-ICOM	140000041	Black FME → ICOM connector for interconnection of FME-cables
FME-EBNC	130000580	FME → elbow-BNC (male) connector
FME-ETNC	130000581	FME → elbow-TNC (male) connector
FME-EMUHF	130000582	FME → elbow-MUHF (male) connector

